Best Paving Practices

For Inspectors and Field Crews

Safety First:


Be aware of overhead obstructions, rollers, dump trucks, paver.

Good Maintenance of Traffic practices are essential



Truck Loading: Use "3 dump method"

Insure proper tarping after loading



Assure proper width, crown, slope, depth

Check that automatic controls are functioning

Monitor mat thickness, appearance, texture



Apply asphalt to clean, dry and properly tacked surface

Maintain hopper capacity (25% min)

Monitor any changes in material



Maintain constant paver speed - no stopping or running conveyor empty.

Maintain constant and proper head of material



504.03.08 Joint Construction:

Straight, longitudinal joints, 1" overlap

No luting or broadcasting material across mat



Roller Pattern

Use control strips to establish roller pattern, correct impact spacing, roller speed

Stagger end of each roller pass



Continuous Paving Operation:

Match roller speed to paving train.

Select a paving speed that balances delivery and paver capacity.



Rollers:

Breakdown: Start rolling immediately to meet coverages for required density.

Final rolling: Achieve density and remove edge marks



Safety first and last!

Be aware of job site traffic movement, as well as pedestrians and workers.





John Shipley, 410-802-7481 Office of Construction

2016 Roundtables

Thank You

